

# TLR ARC INSTALLATION



**PHL** **STER**



Remove screw using included hex key.





Remove o-ring from original switch.





Install o-ring on new switch.







**Install the new switch in  
your preferred orientation.**



Re-install the original screw.



